


# LED Downlight (Triac dimming)

Model No.: DW1-06C-TR

## Diagram Connection With Triac Dimmer



2.4G Remote

**Purchase  
separately**

Triac dimmer

Model No.: TRI-C1 / TRI-C1WR  
TRI-C1ZR

**Purchase separately**

LED Downlight


(Triac dimming)



**Please ensure that every connection is correct before connecting with power source, otherwise it will damage the light**





## Color Temperature Switching

Toggle the color temperature switch on the lamp body to switch warm white (3000K), neutral white (5000K), cold white (7000K)



## Installation Diagram

1. Open hole on ceiling (different model have different size of hole, check details in user manual).
2. Please follow diagram to wire light and put back it into the hole of ceiling
3. Make spring stand up and push it into hole, ensure that it spread and fixed on the back of ceiling (picture 3 and 4)



## Attention

1. Turn off power source while connecting light.
2. Ensure that voltage of power supply is same as light.
3. Don't disassemble light if you are not expert.



Made in China