Mi•Light[®] User Instruction

IP Rate: IP65 RGB+CCT Smart LED Garden Light Model No.: FUTC01 / C02

Features



RGB+CCT 16 Millions of colors to choose



Color temperature 2700~6500K



Dimmable Saturation control



2.4G RF wireless transmission technology



Remote control Control distance 30m



Smart phone App control Mi-Light WiFi ibox is needed



Waterproof and dustproof grade IP65




Beam Angle 15° Illumination distance Greater than 10m




Parameters

Model No.	FUTC01	FUTC02
Input Voltage	DC 24V	AC86~265V / 50~60Hz
Power	9W	9W
Color temperature	2700K~6500K	2700K~6500K
Luminous Flux	700LM	700LM
Light Efficiency	80LM/W	80LM/W
CRI	>80	>80
PF		>0.5
Lifespan	50000 hours	50000 hours
Beam Angle	15°	15°
Illumination distance	>10m	>10m
IP Rate	IP65	IP65
Material	Aluminum	Aluminum



Auto-transmitting Diagram

One Garden Light can transmit the signals from the remote control to another Garden Light within 30m, as long as there is a Garden Light within 30m, the remote control distance can be limitless.




Auto-synchronization function

Different Garden Light can work synchronously when they are started at different times, controlled by the same remote, under same dynamic mode and with same speed.

Remark:

- 1. 🔛 Indicating Auto-transmitting.
- 2. Controller will be auto-synchronizing in the same dynamic modes and within 30m controlling distance.




FUTC01 Connection diagram

Input Voltage DC 24V, don't need to distinguish polarity on the connection



FUTC02 Connection diagram





Link / Unlink

Compatible with FUT089 / FUT092 remote controls (Purchased separately)

Link: Switch off the power, then switch on again after 5 seconds, press " | " 3 times within 3 seconds; the light will blink 3 times slowly when it is done.

Unlink: Switch off the power, then switch on again after 5 seconds, press corresonding " | " or master ON button 5 times within 3 seconds;the light will blink 10 times quickly when it is done.





Caution

Amateur do not dismantle and install the light
Users must be correct, strict and solid to install the light; do not use the light on strenuous vibration area.
The lighting will be heating on working, pls do not cover the lighting housing.