# 10-Key RF Remote Controller

## Model No.: RM3

1 zone RGB or RGBW/10-key/Wireless remote 30m distance/CR2032 battery



### CE RoHS emc LVD RED

### Features

- Apply to RGB or RGBW LED controller.
- Each remote can match one or more receiver.
- CR2032 battery powered.
- Operate with LED indicator light.

## **Technical Parameters**

Input and Output		Safety
Output signal	RF(2.4GHz)	EMC sto
Working voltage	3VDC(CR2032)	Safety s
Working current	< 5 m A	Radio E
Standby current	< 2µA	Certifica
Standby time	2 years	
Remote distance	30m(Barrier-free space)	Warro

Environment		
Operation temperature	Ta: -30°C ~ +55°C	
Case temperature (Max.)	Tc:+85°C	
IP rating	IP20	

EMC standard (EMC) EN301 489,EN 62479   Safety standard(IVD) EN60950   Radio Equipment(RED) EN300 328	Safety and EMC	
/	EMC standard (EMC)	EN301 489,EN 62479
Radio Equipment(RED) EN300 328	Safety standard(LVD)	EN60950
	Radio Equipment(RED)	EN300 328
Certification CE,EMC,LVD,RED	Certification	CE,EMC,IVD,RED

#### arranty

Warranty 5 years

### Mechanical Structures and Installations





Note: Before the first use, please remove the protective film on the battery.

## Match Remote Control (two match ways)

End user can choose the suitable match/delete ways. Two options are offered for selection:

### Use the controller's Match key

Match: Short press match key, immediately press on/off key on the remote. The LED indicator fast flash a few times means match is successful.

#### Delete:

Press and hold match key for 5s to delete all match, The LED indicator fast flash a few times means all matched remotes were deleted.

#### Use Power Restart

Match:

Switch off the power, then switch on power again, immediately short press on/off key 3 times on the remote. The light blinks 3 times means match is successful.

#### Delete:

Switch off the power, then switch on power again, immediately short press on/off key 5 times on the remote. The light blinks 5 times means all matched remotes were deleted.

## Key function



### On/Off: Turn on/off light.

Color: Short press get 24 kinds static RGB color, long press for continuous static color adjustment.



- (6) Mode+: Short press run the next dynamic mode, long press 2s run mode cycle.
- O Mode -: Short press run the previous dynamic mode, long press 2s run the first mode.
- Bright/Speed+: For static RGB color, increase brightness, short press 10 levels, long press 1-6s for continuous 256 levels adjustment. For dynamic mode, increase speed, short press 10 levels, long press get the fastest speed.
- Bright/Speed : For static RGB color, deccrease brightness, short press 10 levels, long press 1-6s for continuous 256 levels adjustment. For dynamic mode, decrease speed, short press 10 levels, long press get the slowest speed.
  - B R/G/B: Short press get red green or blue color directly, long press 1-6s adjust R/G/B brightness continuouslyto achieve millions of colors.
  - W+/-: For RGB light, short press turn on/off white(RGB mix), long press 1-ós adjust saturation continuously namely change current static RGB color to mixed white slowly.
    - For RGBW light, short press turn on/off W channel, long press 1-6s adjust W brightness continuously

### Safety information

- 1. Read all instructions carefully before you begin this installation.
- When installing battery, pay attention to the battery positive and negative polarity. A long time without the remate control, remove the battery. When remote distance becomes smaller and insensitive. realace the battery.
- If no response from the receiver, please re-match the remote.
- 4. Gently handle remote, beware of falling.
- 5. For indoor and dry location use only.