RF Wireless Touching LED Remote Controller

(Brightness Adjusting) [0109]

1. Technical Parameters(remote control):

1:Power supply: AAA battery * 2 pcs

2:Cover material:ABS

2. Technical Parameters(controller):

1. Working voltage:DC12V-24V
2. Output control: 1 circuit
3. Control current：6A/circuit
4. Dimension: L85*W64*H24
5. Receiving range:20meters



3. Functions of Keys

1. Key 1: on
2. Key 2: off
3. Key 3: highest brightness
4. Key 4: medium brightness
5. Key 5: lowest brightness

4. How to use

1. Use your finger to touch the color ring ,you can change the brightness from the highest to the lowest (100%-1%,50 grades to adjust).

2. Resume fuction. The previous settings will be resumed while power on again.

3. Matching code

Press Key 3 once within 3 seconds when power on again,the light will blink 3 times if matching is successful.

Clearing Code

Press Key 3 five times within 3 seconds when power on again,the light will blink 6 times if clearing is successful.

5. Caution

Please don't touch or press the color ring while loading the battaries to protect the sensitiveness. Please use the remote controller 3 seconds after the battaries are loaded.Please reload the battaries when you find the color ring is not sensitive.

6.Connecting chart: