Mi·Light®

User Instruction

WiFi Remote Control

Model No.: YT1

Please read the instructions carefully before using the controller.

1. Features

This WiFi remote controller is compatible with Mi-light 2.4GHz RF products; and controlled by Mi-light Cloud APP through WiFi or 4G network. Two-way signal communication let you know the lighting status at any time. Support Amazon Echo Voice control.

- Support Amazon Alexa Voice Control
- Can control Mi-light 2.4GHz RF series product
- WiFi Wireless Control
- 2.4GHz RF transmission tech
- Smart phone App control
- 16 Millions of colors to choose
- Dimmable Saturation control
- Color temperature 2700-6500K
- Group control randomly by APP
- Timing ON/OFF the lights

2. Parameters

Model No.: YT1

Input: DC5V/500mA (Micro USB)

Working Temperature: -20~60℃

Communication Mode: WiFi-IEEE 802.11b/g/n 2.4GHz

Size: 33*33*57mm

Product Weight: 23g



Smart Link button





INPUT

DC5V/500mA
(Micro USB)

3. Installation

Please install the device within 30m as lights, and approaching the WiFi Router.



4. User Instruction

1. Install APP, and add devices(See details on Mi-light Cloud APP instructions).
2. Click "Remote" on the device list to enter control interface.
3. Click "Change" to select compatible remote for the lights(Note: If you select wrong remote, you cannot control the lights).





4. Click "Link/Unlink".
5. Link/Unlink method, See details on APP link/unlink instruction.
6. After linking successfully, back to the control interface to control the lights randomly.

Note: This WiFi remote controller cannot group control.





Attention

1. Before installation, please check the output voltage is in accordance with the device Rated Voltage.
2. The input voltage is DC5V/500mA, Please do not connect the power supply over DC5V, otherwise, the device will be broken easily.
3. Non-professional user cannot dismantle the divice directly, otherwise, it may cause fire and electric shock.
4. The working temperature is -20~60℃; Do not install the device to direct sunlight, moist and other high temperature area.
5. Please do not install the device around the mental area and high magnetic field, otherwise, it will badly affect the control distance.

RoHS Made in China

iOS ANDROID alexa

Mi-Light Cloud APP User Instruction

1 APP Downloading

For IOS System: Pls search "Mi-Light Cloud" on APP store. (Above IOS9.0)

For Android System: search "Mi-Light Cloud" on Google Play (Above Android 5.0) or Scan below QR-code to download APP.

Scan QR Code to Install APP

iOS APP
App Store

ANDROID APP
Google play

2 Register Mi-Light Cloud Account

Open APP and click Register button;Complete the register and log in.



3 Add Device

1. Click the right top “+” on the device list.
2. Please select the device type you will add, then complete the adding according to the hint of APP.
3. Back to device list after adding successfully, then pull down refresh in list to get the device status.



4 Modify device name or delete device

Slide device list to left, click **" Edit "** to modify device name; click **" Delete "** to delete device.

Note: If the device was shared to others, then the device will also be deleted on your friends' device list.



5 Group Control

1. Click to switch to Group list, then click the right top icon on the Group list to create groups.
2. Slide the Group list to left to **Edit/Delete** groups.

Note: The group just work on APP Controlling, cannot work on Voice control. Please open Amazon APP for Group Voice control.



6 APP Control

Click the device or group that you want to dim on device list and group list into Dimming Interface.

S+ Click speed+ under dynamic mode.

S- Click speed- under dynamic mode.



7 Amazon echo Voice Control

Click left top " ☰ " icon on the home page

Then click " amazon echo " to check detailed instructions



8 Sharing Device

Share the device to friends, Let your friends can control this device.

1. Click the left top " ☰ " icon on the home page.
2. Click " Shared Device " to My sharing, then click**"Add sharing"** (Note: the receiving sharing device cannot be shared again).
3. Click " Jack jack@milight.com " to edit sharing, slide to left to delete sharing.