2 Channel Constant Voltage Power Repeater

Model No.: EV2-W

2 Channel/PWM signal input/Constant voltage output



Features C € RoHS emc LVD

- 12-24V constant voltage power repeater.
- 2 channel, 3A per channel. Using one channel only, 5A Max.
- To receive PWM signal control.
- Power repeater in series or in parallel to expand output unlimitedly.
- Apply to single color or color temperature constant voltage LED strip or module.

Technical Parameters

Input and Output		
Input voltage	12-24VDC	
Input current	6A	
Input signal	12-24V PW/M	
Output voltage	2 x (12-24)VDC	
Output current	2CH,3A/CH Total Max 5A 1CH,Max 5A	
Output power	60-120W	
Output type	Constant voltage	

Safety and EMC	
EMC standard (EMC)	ETSI EN 301 489-1 V2.2.3 ETSI EN 301 489-17 V3.2.4
Safety standard(LVD)	EN 62368-1:2020+A11:2020
Certification	CE,EMC,LVD

Warranty and Protection		
Warranty	5 years	
Protection	Reverse polarity	


Environment	
Operation temperature	Ta: -20°C ~ +55°C
Case temperature (Max.)	Tc:+85°C
IP rating	IP20

Dimension




Wiring Diagram

CCT strip Parallel connection.




Series connection



User Manual Ver 1.0.0

DIM strip Parallel connection

EV2-W 2 Channel Constant Voltage Power Repeater



Malfunctions analysis & troubleshooting

Malfunctions	Causes	Troubleshooting
No light	No power. Wrong connection or insecure.	Check the power. Check the connection.
Wrong color	Wrong connection of WW/CW wires.	1. Reconnect WW/CW wires.
Uneven intensity between front and rear, with voltage drop	Output cable is too long. Wire diameter is too small. Overload beyond power supply capability. Overload beyond controller capability.	Reduce cable or loop supply. Change wider wire. Replace higher power supply. Add power repeater.

Safety & Warnings

- 1. The product shall be installed and serviced by a qualified person.
- 2. This product is non-waterproof. Please avoid the sun and rain.
- 3. Good heat dissipation will prolong the working life of the controller, Please ensure good ventilation.
- 4. Please check if the output voltage of any power supplies used comply with the working voltage of the product.
- Ensure all wire connections and polarities are correct and secure before applying power to avoid any damages to the LED lights.
- 6. If a fault occurs please return the product to your supplier. Do not attempt to fix this product by yourself.

User Manual Ver 1.0.0